


AC24008 Pump Exploded View



AC24008 Pump parts list

| No. | Item code | Qty | |
|-----|------------|-----|--------------------------------------|
| 01 | E100022001 | 12 | Screw |
| 02 | E100022002 | 12 | Cushion |
| 03 | E100022003 | 2 | Cylinder Head |
| 04 | E100022004 | 2 | Seal |
| 05 | E100022005 | 4 | Screw |
| 06 | E100022006 | 4 | Limit Range Implement |
| 07 | E100022007 | 6 | Valve Block |
| 08 | E100022008 | 2 | Valve Board |
| 09 | E100022009 | 2 | O-Ring |
| 10 | E100022010 | 4 | Valve Block |
| 11 | E100022011 | 2 | Valve plate clamp |
| 12 | E100022012 | 2 | Screw |
| 13 | E100022013 | 2 | Cylinder |
| 14 | E100022014 | 2 | Screw |
| 15 | E100022015 | 2 | Valve Board |
| 16 | E100022016 | 2 | Piston Cup |
| 17 | E100022017 | 2 | Connecting Rod |
| 18 | E100022018 | 2 | Heightening the lining |
| 19 | E100022019 | 2 | Wind Scooper |
| 20 | E100022020 | 4 | Screw |
| 21 | E100022021 | 1 | A Fan |
| 22 | E100022022 | 2 | Crank |
| 23 | E100022023 | 2 | Bearing |
| 24 | E100022024 | 4 | Screw |
| 25 | E100022025 | 2 | circlip for shaft |
| 26 | E100022026 | 1 | Screw |
| 27 | E100022027 | 1 | Serrated Lock Washers Internal Teeth |
| 28 | E100022028 | 2 | Power Cord Buckle |
| 29 | E100022029 | 1 | Right Crankcase |
| 30 | E100022030 | 4 | Cushion |
| 31 | E100022031 | 4 | Bolt |
| 32 | E100022032 | 1 | Motor Stator |
| 33 | E100022033 | 1 | Motor Rator |
| 34 | E100022034 | 2 | Bearing |
| 35 | E100022035 | 1 | Left Crankcase |
| 36 | E100022036 | 4 | Nut |
| 37 | E100022037 | 4 | Shock Pad |
| 38 | E100022038 | 4 | Nut |
| 39 | E100022039 | 1 | B Fan |
| 40 | E100022040 | 4 | O-Ring |
| 41 | E100022041 | 2 | Gas-guide Tube |
| 42 | E100022042 | 2 | Hush Pipe |
| 43 | E100022043 | 2 | Air Filter |
| 44 | E100022044 | 1 | Plug |