

MODEL : ASDB1100V/ASDB1200V/ASDB2200V/ASDB2400V

NO.	PARTS NAME	Q
1	CONDUCTION ASS'Y	1
2	BIT	1
3	FRONT COVER SCREW	4
4	FRONT COVER ASS'Y	1
5	CLUTCH B	1
6	SPRING	1
7	GEAR BOX ASS'Y	1
8	O-RING	1
9	GEAR BOX FIXITY	1
10	ROTATOR ASS'Y	1
11	MAIN SWITCH	1
12	FORWARD/REVERSE ROD	1
13	HOUSING LABEL-R	1
14	HOUSING SCREW	8
15	HOUSING-L&R	1
16	CARBON BRUSH	2
17	CARBON BRUSH FIXITY ASS'Y	1
18	CARBON BRUSH COVER	2
19	POWER CORD	1
20	STATOR REAR COVER	1
21	STATOR ASS'Y	1
22	STATOR FRONT COVER	1
23	RUBBER PIN	2
24	PCB ASS'Y	1
25	HANDLE ASS'Y	1
26	WASHER	1
27	HANDLE SCREW	1
28	HOUSING LABEL-L	1
29	HEX WRENCH(3mm)	1
30	HEX WRENCH(4mm)	1

